

## **CAUTION**

The thermostats with floor sensors supplied in our kits (ET630) require at least a three-wire cable. Look for LVT 18/3 thermostat cable. The cable needs to be run from the thermostat location to the location where the panel will be installed. It will allow the thermostat to control different components on the panel.

For more information on installing your system, visit our website: https://plancherchauffant.com/

The "Installation" section includes a series of videos demonstrating each step.

